



- 1) **Remove existing door handles** – To remove the OEM door handles pull open the handle and locate the T20 TORX screw behind and at the front of the handle. While holding the handle open remove the screw and slide the handle towards the front of the car. The door handle mount will spring back into place. Retain the T20 TORX screw for reuse.
  
- 2) **Fitting the MRN door pull** – To fit the door pull, pry out the mount and slide the MRN door pull part over it then refit the T20 TORX screw that was removed in step 1. Overtightening can cause the thread to strip out of the OEM door mechanism so use caution.
  
- 3) **Test operation** – the MRN door pull should fit perfectly to the contours of your door panel, if it does not you can loosen the T20 TORX screw, hold the door pull where the fit will be improved then retighten the screw. A pull on the coloured webbing will open your door the same way as the OEM handle.
  
- 4) **Maintenance** – The MRN door pull are maintenance free. Cleaning can be undertaken as per your usual interior cleaning regime using cleaning products intended for vehicle interiors.